

## The instructions for TALKING WATCH

### How it works

Tap the "TALKING" button for time announcements.

### To set the time

Turn the function tuner to the "TS" (Time Set) position. Press the "H" and "M" keys continuously until the correct hour and minute is displayed. (alternatively to advance the hour and minute rapidly, press the hour and minute keys in and out repeatedly.)

Turn the function tuner to "TIME" position.

### To set alarm time

Turn the function tuner to "AS" (Alarm Set) position. Set the desired alarm time in the same way as for setting time. Turn the function tuner to "TIME" position. The alarm will sound at the time set and will last for one minute if there is no interruption. **Stop the alarm sound by tapping the "TALKING" button** (the sound will stop after one time's announcement).

Turn the function tuner "ALM OFF" position to delete this function.

### To change the battery

Loosen the four screws on the back cover (Fig. 1). Remove the battery hatch and follow the diagram showing the polarity (Fig. 2) to change the battery.

Replace the hatch and fastened the screws.



(Fig. 1)



(Fig. 2)

### Battery used

The TALKING WATCH runs on one **CR2016 (Lithium)** battery. Normal operating life is estimated to be **3 years** (based on 30 seconds operating time each day).

### ATTENTION

if the LCD screen fades and the sound becomes weak or the function is abnormal, please change the battery.