



Loud Ringer Light Box

OWNER'S MANUAL AND OPERATING INSTRUCTIONS

● FEATURES

- 3 Ring Tone Adjustable by Switch
- 3 Ring Volume adjustable by Switch
- Incoming Call Bright Light Indicator
- Operate with Simple Connection to Line Phone
- In and out RJ11 jacks for Easy and Quick Installation
- No Batteries or AC Adaptor Needed
- Wall Mountable

● SETTING

1. Ringer Volume Control (HI/LO/OFF)

- Slide the [RINGER] switch to 'HI' position or 'LO' position to turn the ringer on. 'HI' for high volume and 'LO' for low volume
- Slide the [RINGER] switch to 'OFF' position to turn the ringer off. You still can dial out, but cannot hear ringer sound of any incoming calls via this box only.
- (Ringer LED'S will still flash to remind you there is incoming call.) Don't forget to switch the ringer to 'ON' (i.e. 'HI' or 'LO' position), otherwise, you cannot hear the ringer sound next time from this box.

2. Ringer Tone Adjustable

- Sliding the RINGERTONE switch among 1, 2 & 3 to select the ringer tone type.

3. Incoming Call Light Indicator

- The LED'S will light when there is any incoming call.

● OPERATION

- When there is new incoming call, the ringer box will alarm with a loud ringing sound and bright LED'S lights.

SAFETY INSTRUCTIONS

- This telephone is an electrical device and can be hazardous if immersed in water. If you accidentally drop it into water, first unplug it from wall jack, and remove it from water.
- Please keep the telephone dry and do not use it in moisture place. For example, near a bathtub, washbowl, kitchen sink, laundry tub and swimming pool. Do not use it in rain.
- Unplug the unit from the wall jack before cleaning with damp cloth; please do not use liquid or aerosol cleanser.
- Do not use the unit to report a gas leak in the gas vicinity. Please remove yourself immediately from the area and make the emergency phone call in a safe area.
- Handle the phone carefully. Do not drop it.
- Do not use or put the unit in extreme temperature.
- Keep the phone away from dust and dirt.
- Use the right power batteries indicated in the manual. Do not put batteries in a fire for such action can lead to an explosion.
- Do not modify or tamper with the unit's internal components. Improper adjustment can cause damage and can be dangerous.

SAVE THESE INSTRUCTIONS

ITEM NUMBER 5683

FCC Number GXACHN-25749-TE-E

FUTURE CALL LLC

For services call us Toll free on 1-888-934-CALL (2255)

E-mail help@future-call.com

Visit us on the web www.future-call.com